




FLEXMATE S500 SHOULDER CPM






CONTROLLER BAY WHEN IN USE



CONTROLLER PENDANT STORAGE

TRANSFORMER STORAGE



MOTOR DRIVER PCB

